




Plate Compactor Operator's Manual



WARNING:

Carefully review and understand all INSTRUCTIONS prior to operating this device. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury. Keep these instructions in a safe place and accessible so that they can be reviewed as required. Keep these instructions to assist in future servicing needs.

WARNING

Understand Your Machine

1. Read and understand the operator's manual and labels affixed to the machine. Learn its proper usage and capabilities as well as the specific potential hazards unique to this product.
2. Be thoroughly familiar with the controls and their proper operation. Know how to stop the machine and disengage the controls quickly before operating the product.
3. Make sure to read and understand all the instructions and safety precautions as outlined in the Engine Manual. This manual is included with your unit. Do not attempt to operate the machine until you fully understand how to properly operate and maintain the Engine and how to avoid accidental injuries and/or property damage.

Work Area

1. Never start or run the engine inside a closed area. Exhaust fumes produced by gasoline engines are dangerous, containing carbon monoxide, an odorless and deadly gas. Operate this unit only in a well ventilated outdoor area.
2. Never operate the machine without good visibility and lighting.

Personal Safety

1. Do not operate the machine while under the influence of drugs, alcohol, or any medication that could impair your motor coordination and ability to use it properly.
2. Dress properly. Wear sturdy long pants, boots and gloves. Do not wear loose fitting clothing, short pants, or jewelry of any kind. Secure long hair so it is out of the way and preferably above shoulder level. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts resulting in severe injury.
3. Check your machine before starting it. Keep guards in place and in working order. Make sure all nuts, bolts, etc. are securely tightened.
4. Never operate the machine when it is in need of repair or is in poor mechanical condition.
5. Replace damaged, missing or failed parts before using it. Check for fuel leaks. Keep the machine in safe working condition.
6. Do not use the machine if the engine's switch does not turn it on or off. Any gasoline powered machine that can not be controlled with the engine switch is dangerous and should not be operated.
7. Check to see that keys and adjusting wrenches are removed from machine area before starting it. A wrench or a key that is left attached to a rotating part of the machine may result in personal injury.
8. Stay alert, watch what you are doing and use common sense when operating the machine.
9. Do not overreach. Do not operate the machine while barefoot or when wearing sandals or similar lightweight footwear. Wear protective footwear that will protect your feet and improve your footing on slippery surfaces. Maintain proper footing and balance at all times. This enables better control of the machine in unexpected situations.
10. Avoid accidental starting. Be sure the engine's switch is off before transporting the machine or performing any maintenance or service on the unit. Transporting or performing maintenance or service on a machine with its switch in the on position invites accidents.

Fuel Safety

1. Fuel is highly flammable, and its vapors can explode if ignited. Take precautions when using to reduce the chance of serious personal injury.
2. When refilling or draining the fuel tank, use an approved fuel storage container while in a clean, well-ventilated outdoor area. Do not smoke, or allow sparks, open flames or other sources of ignition near the area while adding fuel or operating the unit. Never fill fuel tank indoors.

3. Keep grounded conductive objects, such as tools, away from exposed, live electrical parts and connections to avoid sparking or arcing. These events could ignite fumes or vapors.
4. Always stop the engine and allow it to cool before filling the fuel tank. Never remove the cap of the fuel tank or add fuel while the engine is running or when the engine is hot. Do not operate the machine with known leaks in the fuel system.
5. Loosen the fuel tank cap slowly to relieve any pressure in the tank.
6. Never overfill fuel tank (there should be no fuel above the upper limit mark).
7. Replace all fuel tank and container caps securely and wipe up spilled fuel. Never operate the unit without the fuel cap securely in place.
8. Avoid creating a source of ignition for spilled fuel. If fuel is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until fuel vapors have dissipated.
9. Store fuel in containers specifically designed and approved for this purpose.
10. Store fuel in a cool, well-ventilated area, safely away from sparks, open flames or other sources of ignition.
11. Never store fuel or machine with fuel in the tank inside a building where fumes may reach a spark, open flame, or any other source of ignition, such as a water heater, furnace, clothes dryer and the like. Allow the engine to cool before storing in any enclosure.

Machine Use and Care

1. Never pick up or carry a machine while the engine is running.
2. Do not force the machine. Use the correct machine for your application. The correct machine will do the job better and safer at the rate for which it was designed.
3. Do not change the engine governor settings or over-speed the engine. The governor controls the maximum safe operating speed of the engine.
4. Do not run the engine at a high speed on areas that you are not intending to compact.
5. Do not put hands or feet near rotating parts.
6. Avoid contact with hot fuel, oil, exhaust fumes and hot surfaces. Do not touch the engine or muffler. These parts get extremely hot from operation. They remain hot for a period of time after you turn off the unit. Allow the engine to cool before doing maintenance or making adjustments.
7. If the machine should start to make an unusual noise or vibration, immediately shut off the engine, disconnect the spark plug wire, and check for the cause. Unusual noise or vibration is generally warning of trouble.
8. Use only attachments and accessories approved by the manufacturer. Failure to do so can result in personal injury.
9. Maintain the machine. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the machine's operation. If damaged, have the machine repaired before use. Many accidents are result of poorly maintained equipment.
10. Keep the engine and muffler clear. Clean and free of grass, leaves, excessive grease or carbon build up to reduce the chance of a fire hazard.
11. Never douse or spray the unit with water or any other liquid when in use. Keep handles dry, clean and free from debris. Clean after each use.
12. Observe proper disposal laws and regulations for gas, oil, etc. to protect the environment.
13. Store idle machine out of the reach of children and do not allow persons unfamiliar with the machine or these instructions to operate it.

Service









1. Before cleaning, repair, inspecting, or adjusting, shut off the engine and make certain all moving parts have stopped. Always make sure the engine's switch is in its "OFF" position. Disconnect the spark plug wire, and keep the wire away from the plug to prevent accidental starting.
2. Have your machine serviced by a qualified repair personnel using only approved replacement parts. This will ensure that the safety of the machine is maintained.

Specific Safety Rules

1. To avoid injury, keep hands, fingers and feet away from the base plate. Grip the handle of the plate compactor firmly with both hands while operating.
2. Always operate the machine from behind, never pass or stand in front of the machine when the engine is running.
3. This product is intended for dirt and gravel compaction only. It is not intended for crushing any other foreign objects.
4. If the unit strikes a foreign object, stop the engine, disconnect the spark plug, thoroughly inspect the machine for any damage, and repair the damage before restarting and operating the machine.
5. Never operate the unit at high speed setting on hard (example: concrete or pavement) or slippery surfaces.
6. Exercise extreme caution when operating on or crossing gravel drives, walks, or roads. Stay alert for hidden hazards or traffic. Do not carry passengers or attempt to ride the compactor.
7. Never leave a plate compactor unattended when the engine is running.
8. Always stop the engine when compacting is delayed or when moving from one compacting area location to another.
9. Stay away from the edged of ditches or other steep embankments. Avoid actions that may cause the plate compactor to topple over.
10. Always ascend slopes carefully in a direct path and in reverse to prevent the plate compactor from toppling over onto the operator.
11. Always park the unit on a firm and level surface and shut the tool off.
12. Prolonged usage and exposure to vibration will cause hand and muscle fatigue. Limit the hours of continuous operation and take periodic breaks to minimize repetition and rest your hand. Reduce the speed and force in which you do the repetitive movement. Try to fill each day with jobs where operating hand-held power equipment is not required.

SAFETY SYMBOLS

The rating plate on your machine may show symbols. These represent important information about the product or instructions on its use.

	Read these instructions for use carefully.		It is forbidden to remove or tamper with the protection devices and safety devices.
	Wear eye protection. Wear hearing protection.		Keep away from rotating parts.
	Wear protective gloves.		Do not touch parts which are hot from operation. Serious burns may result.
	Wear safety footwear.		Do not smoke or have open flames.

Use extreme caution when storing, handling and using fuels, as they are highly volatile and explosive in vapor state.




Keep children and bystanders off and away.

TECHNICAL SPECIFICATIONS

Item No.	GUO090
Plate Size	20"x15"
Centrifugal Force	4200lbf
Exciter Speed	5500rpm
Compaction Depth	12"
Travel Speed	115FT/min
Operation Weight	135lb

MAIN COMPONENTS




ASSEMBLY


Contents Supplied

The plate compactor comes partially assembled and is shipped in carefully packed carton. After all the parts have been removed from the carton, you should have:

1. Plate Compactor Chassis with Engine and Transmission
2. Handle
3. Handle Bracket
4. Handle Connecting Shaft
5. Wheels Kit
6. Operator's Manual
7. Two hooks
8. Two rubber blocks
9. Water pipe
10. Water pipe support




1. Handle Bracket




- a. Pass M6x40 hex flange bolts (A) into the hose of handle bracket (B).
- b. Go through two M6 large washers (C) and one hook (D). The hook (D) is between two M6 large washers (C).
- c. Fix M6 hex lock nut (E), the hook (D) can rotate freely.

2. Wheels Kit




Install the two wheels (B) on the wheel support frame (A), and fix them with two flat washers (C) and pins (D).

3. Handle Bracket & Wheels Kit




- Place the wheel set (A) at inside of the engine base plate (C), and handle bracket (B) at outside.
- Align the shaft sleeve hole and the base plate hole (D), insert the shaft (E) into them.
- Fix them with two M12 flat washers (F) and M12 hex lock nuts (G) at both sides.

4. Rubber Blocks




- Assemble two rubber blocks (A) to base plate, fix with two M10 flat washers (B) and two M10 hex lock nuts (C) both sides.




- Before compacting, fold up the Wheel Kit by hook.

5. Handle




- Place the handle (A) at the inside of the bracket (B) and align the mounting holes.
- Fix with 4pcs M8 × 20 hexagon head flange bolts (C) and 4pcs M8 hexagon flange lock nuts (D).

6. Throttle Control



Install the throttle control (A) on the handle (B) and fix it with the bolts which provided together with throttle control.

7. Water Pipe



- Firstly, remove the two nuts (A) at base plate.
- Install the water pipe support (B) on the base plate, and then fix it with nuts (A).
- Install the water pipe (C) to the support (B) and the water valve (D), and close them by two clamps (E).

OPERATION

Adding Engine Oil

▲WARNING

OIL HAS BEEN DRAINED FOR SHIPPING.

Failure to fill engine sump with oil before starting engine will result in permanent damage and void engine warranty.

Add oil according to Engine Manual

Adding Fuel

- Fill the fuel tank as instructed in the separate Engine Manual.
- More detailed description of the engine operation and all related precautions and procedures can be found in the Engine Manual.

Starting Engine

1. Move the fuel valve lever to the ON position.
2. To start a cold engine, move the choke to the CLOSE position. To restart a warm engine, leave the choke lever in the OPEN position.
3. Move the throttle lever away from the SLOW position, about 1/3 of the way toward the FAST position.
4. Turn the engine switch to the ON position.
5. Operate the starter.

Operating compactor



Do not operate plate on concrete or on extremely hard, dry, compacted surfaces. The plate will jump rather than vibrate and could damage both plate and engine.

1. After engine warms up, pull throttle lever to accelerate engine speed. Plate will begin vibrating and move forward.
2. The plate compactor is designed to run at an engine speed of 3600rpm (considered full throttle). Running the engine at lower rpm will result in a decrease of compaction force and lower travel speed. It will create excessive "out-of-synch" vibrations resulting in poor compaction and maneuverability, excessive wear to the machine, and discomfort to the operator.
3. During operation, guide the machine, but let the compactor do the work. Bearing down on the handle is unnecessary and will cause excess shock and vibration transfer to the operator and excessive shock and vibration wear to the product.
4. Product should move smoothly and rapidly over level surfaces. Over uneven surfaces or on inclines, operator may need to apply light forward pressure on handle may be required to assist the compactor.
5. The number of passes required to reach a desired compaction level will depend upon the type and moisture content of soil. Maximum soil compaction has been reached when excessive kickback is noticed.
 - When using a compactor on asphalt, a Water Sprinkler Kit is required to help prevent the bottom plate from adhering to the hot asphalt surface.
 - When using plate on paving stones, attach a pad to the bottom of the plate to prevent chipping, scratching or grinding the surface of the stones. A special urethane pad designed for this purpose is available as an optional accessory.
 - While a certain amount of moisture in the soil is necessary for tight compaction, excessive moisture will prevent solid compaction. If soil is extremely damp or muddy condition, allow it to dry before compacting.
 - If soil is so dry as to create dust clouds while operating plate, some moisture should be added to the ground to improve compacting. This will also reduce service to the air filter.
6. The water in tank reservoir can be utilized for reducing dust creation and during asphalt projects. Open top cover and fill tank with water. Open the flow valve, water will be allowed to flow out from holes in the water pipe support. Close valve if reservoir is empty and needs refilling or after project is complete. Drain tank and allow to dry if storing the unit between projects.

Stopping Engine

To stop the engine in an emergency, simply turn the engine switch to the OFF position.

Under normal conditions, use the following procedure.

1. Move the throttle lever to the SLOW position.
2. Let engine idle for one or two minutes.
3. Turn the engine switch to the OFF position.
4. Turn the fuel valve lever to the OFF position.

⚠ WARNING

Do not move choke control to **CLOSE** to stop engine. Backfire or engine damage may occur.

Idle Speed

Set throttle control lever to its "low" position to reduce stress on the engine when compacting is not being performed. Lowering the engine speed to idle the engine will help extend the life of the engine, as well as conserve fuel and reduce the noise level of the machine.

MAINTENANCE AND STORAGE

Preventive Maintenance

1. Turn off engine. Engine must be allowed to cool before storing the unit.
2. Keep the engine's throttle lever in its SLOW position, and remove spark plug wire from spark plug and secure.
3. Inspect the general condition of the plate compactor. Check for loose screws, misalignment or binding of moving parts, cracked or broken parts, and any other condition that may affect its safe operation.
4. Remove all debris from the plate compactor with a soft brush, vacuum, or compressed air. Then use a premium quality lightweight machine oil to lubricate all moving parts.
5. Clean the bottom of the compactor base as soon as it begins to pick up soil being compacted. The unit can not do a good job if the bottom surface is not smooth and clean.
6. Replace spark plug wire.

⚠ WARNING

Never use a "pressure Washer" to clean your plate compactor. Water can penetrate tight areas of the unit and cause damage to spindles, pulleys, bearings, or the engine. The use of pressure washers will result in shortened life and reduce serviceability.

Checking V-Belt


To ensure optimum power transmission from the engine to the eccentric shaft, the V-belt must be in good condition and operate under proper tension.

1. Turn off engine. Engine must be cool.
2. Remove the belt guard to access the V-belt.
3. Check the condition of the V-belt. If any V-belt is cracked, frayed, or glazed, it should be replaced as soon as convenient.
4. Check the V-belt tension by squeezing them in the center. The normal deflection on each side should be 9mm (3/8") to 13mm (1/2") with moderate pressure from your thumb or finger.
5. On new machines or after installing a new belt, check belt tension after first 20 hours of operation. Check and adjust belt every 50 hours thereafter.


Tensioning V-Belt

Proper belt tension is critical to good performance. Proper adjustment will assure long belt life. Too much or too little belt tension will cause premature belt failure.


1. Loosen 4 engine mount bolts (do not remove) only enough to move the engine forward.



1. Loosen 4 engine mount bolts (do not remove) only enough to move the engine forward.



2. Loosen the jam nuts (A), leaving enough space between the nut and bracket (B).



3. Push engine toward the back of the plate to remove any slack in V-belt.
4. When adjusting the belt, make sure that the clutch pulley is in alignment with exciter pulley.


5. When the V-belt tension is correct, tighten the jam nuts A against the bracket.
 6. Tighten the engine mount bolts.
 7. Replace the belt guard.
- If the adjustment bolts have no more adjustment left, the belt may have to be replaced.

Replacing V-Belt

1. Loosen 4 engine mount bolts (do not remove) only enough to move the engine forward.
2. Loosen the jam nuts A shown in above figure.
3. Slide the engine toward the front of plate and slip the old V-belt off of the wheel pulley and install the new V-belt in their place.
4. Position the V-belt over the engine pulley.
5. Move the engine back.

▲WARNING

When adjusting the belt, make sure that the clutch pulley is in alignment with exciter pulley.




6. When the V-belt tension is correct, tighten the jam nuts A and the engine mount bolts.
7. Replace the belt guard.

⚠ WARNING


When removing or installing the drive belt, be careful not to get your fingers caught between the belt and pulley.

Exciter Lubrication


The exciter housing is pre-serviced using Automatic Transmission Fluid Dextron I, Mercon, EXXON(ESSO) NUTO H-32 or its equivalent. Change fluid after 200 hours of operation.



1. Let exciter cool before changing exciter oil.
2. Remove the belt guard (A), V-belt (B), and baffle (C).
3. Loosen the clamp (E) and remove the water pipe support (F). Remove the bolts that hold the deck to the housing.
4. Lift entire deck with engine from housing.



5. Remove pipe plug (D) from top of exciter housing. Tilt housing upside down so oil drains from exciter. Examine oil for metal chips as a precaution to future problems.
6. Return plate housing to the upright position.



7. Fill the exciter housing with exciter oil.

▲WARNING

Do not overfill. Overfilling can result in excessive temperatures in the exciter.

8. Apply pipe sealant to pipe plug and reinstall into top of exciter housing.
9. Reinstall deck, V-belt and belt guard.

Engine maintenance

Refer to the Engine Manual included in your plate compactor for the information on engine maintenance. Your engine manual provides detailed information for performing the tasks.

Storage

If the plate compactor will not be used for a period longer than 30 days, following the steps below to prepare your unit for storage.

1. Drain the fuel tank completely. Stored fuel containing ethanol or MTBE can start to go stale in 30 days. Stale fuel has high gum content and can clog the carburetor and restrict fuel flow.
2. Start the engine and allow it to run until it stops. This ensures no fuel is left in the carburetor. Run the engine until it stops. This helps prevent deposits from forming inside the carburetor and possible engine damage.
3. While the engine is still warm, drain the oil from the engine. Refill with fresh oil of the grade recommended in the Engine Manual.
4. Allow the engine to cool. Remove the spark plug and put 60 ml of SAE-30 of high quality motor oil into the cylinder. Pull the starter rope slowly to distribute the oil. Replace the spark plug.


▲WARNING

Remove the spark plug and drain all of the oil from the cylinder before attempting to start the unit after storage.

5. Use clean clothes to clean off the outside of the compactor and to keep the air vents free of obstructions.

▲WARNING

Do not use strong detergents or petroleum based cleaners when cleaning plastic parts. Chemicals can damage plastics.



6. Fold up the wheels bracket.
7. Pull up the bolt and carefully fold the upper handle down. Do not allow control cables to become pinched or bent.
8. Store your plate compactor in upright position in a clean, dry building that has good ventilation.

TRANSPORTING

See technical data for the weight of the machine. To avoid burns or fire hazards, let engine cool before transporting machine or storing indoors. The unit must be transported in the upright position to prevent fuel from spilling. Do not lay machine on its side or top. Secure or tie down unit using the lifting handle to prevent machine from sliding or tipping over.

▲WARNING

Machine may fall and cause damage or injury if lifted incorrectly. Lift using handles at base of plate.


WARRANTY

Twelve (12) months for workmanship of the product, except for wearing parts. Warranty period starts from the product purchase date. Warranty covers material quality and workmanship only. Warranty does not cover product for issues caused by improper usage or any operation not in accordance with the specifications of this manual. Any modification or tampering with the product in any way voids the warranty.

TROUBLE SHOOTING

Problem	Cause	Remedy
Engine fails to start.	1. Spark plug wire disconnected.	1. Attach spark plug wire securely to spark plug.
	2. Out of fuel or stale fuel.	2. Fill with clean, fresh gasoline.
	3. Throttle control lever not in correct starting position.	3. Move throttle control lever to start position.
	4. Choke not in ON Position.	4. Throttle must be positioned at choke for a cold start.
	5. Blocked fuel line.	5. Clean the fuel line.
	6. Fouled spark plug.	6. Clean, adjust gap, or replace.
	7. Engine flooding.	7. Wait a few minutes to restart, but do not prime.
Engine runs erratically.	1. Spark plug wire loose.	1. Connect and tighten spark plug wire.
	2. Unit running on CHOKE.	2. Move choke lever to OFF.
	3. Blocked fuel line or stale fuel.	3. Clean fuel line. Fill tank with clean, fresh gasoline.
	4. Vent plugged.	4. Clear vent.
	5. Water or dirt in fuel system.	5. Drain fuel tank. Refill with fresh fuel.
	6. Dirty air cleaner.	6. Clean or replace air cleaner.
Engine overheats.	1. Engine oil level low.	1. Fill crankcase with proper oil.
	2. Dirty air cleaner.	2. Clean air cleaner.
	3. Air flow restricted.	3. Remove blower housing and clean.
Engine will not stop when throttle control is positioned at stop, or engine speed does not increase properly when throttle control is adjusted.	Debris interfering with throttle linkage.	Clean dirt and debris.
Compactor is difficult to control when pounding(machine jumps or lurches forward).	Too high engine speed on hard ground.	Set the throttle lever at lower speed.

EXPLODED AND PARTS LIST



Part No.	Description	Q'ty
1	M8x25 hex flange bolts	6
2	Compactor base plate	1
3	M8 Non-metallic insert hex flange lock nut	11
4	Base rubber block	4
5	M10 Large washer	4
6	M10 Standard elastic washer	8
7	M10 Type 1 Non-metallic insert hex lock nut	10
8	Two-end threaded shaft	1
9	M12 Flat washer	4
10	M12 Type 1 Non-metallic insert hex lock nut	2
11	Handle rubber block	2
12	M10 Flat washer	6
13	Engine	1
14	M8x20 Hex flange bolts	4
15	Throttle control	1
16	Handle	1
17	M6 Type 1 Non-metallic insert hex lock nut	2
18	M6 Large washer	4
19	M6x40 Hex flange bolts	2
20	Wheel hook	2
21	Wheel	2
22	B Type pin	2
23	Handle bracket	1
24	Wheel bracket	1
25	M8 Large washer	3
26	M8x45 Hexagon head bolt	1
27	M8 Elastic washer	12
28	Belt Guard	1
29	Belt	1
30	M10x25 Hex flange bolt	1
31	Belt cover baffle	1
32	M8x25 Hexagon head bolt full	5
33	Exciter pulley baffle	1
34	Exciter pulley	1
35	Exciter pulley flat key	1
36	Rubber	1
37	Engine flat key	1
38	Engine pulley	1
39	M8x30 Hexagon head bolt	1
40	M10 Hex flange nut	1
41	Engine adjusting bracket	1
42	M8 Type 1 Non-metallic insert hex lock nut	4

Part No.	Description	Q'ty
43	M8 Flat washer	8
44	Engine base	1
45	M8x40 Half round head square neck bolt	3
46	M16x10 Hexagon head bolt	1
47	Sealing ring	1
48	M6 Flat washer	16
49	M6x25 hexagon head bolt	16
50	Engine pulley baffle	1
51	Engine bolt	1
52	M8x45 Half round head square neck bolt	1
53	Buffer block	1
54	Water tank support	1
55	Water tank	1
56	Water tank cover	1
57	Screw	1
58	Water valve	1
59	Water pipe	1
60	Clamp	2
61	Water pipe support	1



Great Circle USA
help@greatcircleus.com
support line: 1-866-493-0524
www.greatcircleus.com